

## FITTING INSTRUCTION FOR PFR1-211 BUSH

Thank you for purchasing one of the advanced range of POWERFLEX polyurethane suspension bushes.

The centre sleeve for this bush has been supplied to original factory dimensions, however the centre pin on your De Dion tube may well be worn. This means the new sleeve may be a loose fit. Modification work may be required to ensure a tight fit of the centre stainless sleeve to the original.

Always check suspension alignment after fitting POWERFLEX bushes.

Should you experience any technical difficulties in any way please contact our technical Hotline. (+44) 01895 460033



Visit our channel for video instructions YouTube.com/PowerflexEPTG



## FITTING INSTRUCTION FOR PFR1-211 BUSH

Thank you for purchasing one of the advanced range of POWERFLEX polyurethane suspension bushes.

The centre sleeve for this bush has been supplied to original factory dimensions, however the centre pin on your De Dion tube may well be worn. This means the new sleeve may be a loose fit. Modification work may be required to ensure a tight fit of the centre stainless sleeve to the original.

Always check suspension alignment after fitting POWERFLEX bushes.

Should you experience any technical difficulties in any way please contact our technical Hotline. (+44) 01895 460033



Visit our channel for video instructions YouTube.com/PowerflexEPTG



## FITTING INSTRUCTION FOR PFR1-211 BUSH

Thank you for purchasing one of the advanced range of POWERFLEX polyurethane suspension bushes.

The centre sleeve for this bush has been supplied to original factory dimensions, however the centre pin on your De Dion tube may well be worn. This means the new sleeve may be a loose fit. Modification work may be required to ensure a tight fit of the centre stainless sleeve to the original.

Always check suspension alignment after fitting POWERFLEX bushes.

Should you experience any technical difficulties in any way please contact our technical Hotline. (+44) 01895 460033



Visit our channel for video instructions YouTube.com/PowerflexEPTG



## FITTING INSTRUCTION FOR PFR1-211 BUSH

Thank you for purchasing one of the advanced range of POWERFLEX polyurethane suspension bushes.

The centre sleeve for this bush has been supplied to original factory dimensions, however the centre pin on your De Dion tube may well be worn. This means the new sleeve may be a loose fit. Modification work may be required to ensure a tight fit of the centre stainless sleeve to the original.

Always check suspension alignment after fitting POWERFLEX bushes.

Should you experience any technical difficulties in any way please contact our technical Hotline. (+44) 01895 460033



Visit our channel for video instructions YouTube.com/PowerflexEPTG